

## PROPANE HEATER

### *Safety Precautions:*

This is a propane, direct-fired, forced air heater. Its intended use is primarily temporary heating of buildings.

- \* Mount the propane cylinder vertically (shutoff valve up). Secure them from falling or being knocked over and protect them from damage.
- \* Locate propane container at least 7 ft from the heater and do not direct exhaust toward container.
- \* For indoors use only. Area must be well ventilated. Provide minimum openings of 1 sq. ft. near the floor and 1 sq. ft. near the ceiling.
- \* If at any time gas odor is detected, **IMMEDIATELY DISCONTINUE** operation until the source of gas has been located and corrected.
- \* Install the heater such that it is not directly exposed to water spray, rain and/or dripping water.
- \* Maintain minimum clearance from normal combustible material (like paper) as follows: floor-0 ft; outlet-6 ft; sides-2 ft and top-2 ft.

Locate 10 ft from canvas or plastic tarpaulins or similar coverings and secure them to prevent flapping or movement due to wind action.

- \* Operate only on stable, level surface.
- \* Do not use with ductwork. Do not restrict inlet or exit.
- \* Use only a properly grounded 3-prong receptacle or extension cord.
- \* Do not move, handle or service while hot or burning.

### **Operating Instructions**

- \* Connect the POL fitting of hose and regulator assembly to the propane cylinder by rotating the POL nut counter-clockwise into the propane cylinder's valve outlet and securely tighten with a wrench.
- \* Connect the hose to the heater by rotating the hose fitting clockwise.
- \* Securely tighten all gas connections.
- \* Open the cylinder's gas valve and check all gas connections with a soap and water solution. Do not use a flame.
- \* Connect power cord to well-grounded source of power.

- \* When using an extension cord, make certain that it is a 3-wire (grounded) cord of proper wire size.

***Start:***

- \* Slowly open the main valve at propane cylinder.
- \* Depress the fuel valve button.
- \* After the heater lights keep the gas valve button depressed for 15 seconds then release and the heater will continue to operate.

***Stop:***

- \* Securely close valve on the propane cylinder.
- \* Continue to operate heater until all fuel in the hose has burned.
- \* Unplug the power cord.

If you need to restart the heater, wait 5 minutes and then restart following "Start" procedure.

**IF YOU HAVE ANY PROBLEMS OR QUESTIONS, PLEASE CALL RENTAL STOP  
817-336-0059.**